

Ez-Tex Mist & Deck Coat Hopper Gun Assembly



Note:

Recommended to remove the air needle after each use, clean and lube O-ring then assemble back into the gun.

Steps:

1. Remove front spray nozzle
2. Remove back air needle adjustment
3. Push needle from the front of the gun out.



3 options for air connection to the gun